


Axle Fit Guide

Find the Burley Through Axle that is right for you!

1. Print this sheet on a standard 8.5"x11" letter sheet. Verify that the illustrations are to scale by using this ruler.



2. Check the thread pitch of your current axle by comparing it to the illustrations here.



1mm




1.5mm



1.75mm

3. Measure the length of your current axle using this illustration. Measure to the end of the threads.



4. Use the thread pitch and axle length to determine which model of Thru Axle you need. If your axle length is not shown for the thread pitch you have, we do not have a compatible thru axle for you at this time.

Thread Pitch	Measured Axle Length	Compatible Burley Thru Axle	SKU
1.0	~160-174 mm	12x1.0, 142-148 mm	960120
1.5	~172-178 mm	12x1.5, 142-148 mm	960121
1.5	~229 mm	12x1.75, 197 mm	960124
1.75	~174-180	12x1.75, 142-148 mm	960122
1.75	~229	12x1.75, 197 mm	960123